
## Charred Oak Log Placement Instructions (16" model)


This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46 & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.



1

## Charred Oak Log Placement Instructions (18/20" model)


This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46 & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.





## Charred Oak Log Placement Instructions (24" & 30" model)

This charred log set includes an ember screen and glowing embers. For G4 & G45 Series Burner Systems; refer to the main owner's manual for screen and embers installation. For G46 & "P" Series Burner Systems; DISCARD the screen and embers as they are not applicable.



3

## LOG SET NOTES PAGE

Please use this page to record any information about your log set that you may want to have at hand.